


MENABO

your freetime on the move



SHERMAN






CZ	Návod na montáž	LV	Pritvirtinimo instrukcijas
DE	Montageanleitung	NO	Monteringsveiledning
DK	Monteringsvejledning	NL	Montage-instructies
ES	Instrucciones de montaje	PL	Instrukcja montażu
EST	Paigaldusjuhend	PT	Instruções de Montagem
FIN	Asennusohje	RO	Instrucțiuni de montare
FR	Instructions de montage	RU	Инструкции по установке
GB	Fitting instructions	SE	Monteringsanvisning
GR	Οδηγίες συναρμολόγησης	SLO	Navodila za pritrjevanje
HR	Uputa za sastavljanje	SK	Návod na montáž
HU	A felszerelés módja	TK	Uydurma talimat
IT	Istruzioni per il montaggio	中文	裝修指導
LT	Stiprināšanas instrukcija	العربية	تعليمات التحميل







N	Componenti (Inclusi) Components (Included) Composants (Comprises) Die Komponenten (im Lieferumfang enthalten) Componentes (Incluido) Компоненты (в комплекте)	Q
1		2
2		2
3	xxxx	2
4		2

N	Ricambi (A Richiesta) Spare Parts (Made to order) Pièces de rechange (Sur commande) E Teile (auf Anfrage) Piezas de recambio (Previa solicitud) Запасные части (по запросу)	Q	Codice - Code Código - код
2		2	700007900000
3	xxxx	2	700007800000
4		1	700025000000
5	+ xxxx	2	700030900000
6		1	700031000000
7		4	700031100000







Sherman XL	3,9 kg		